## <u>Mathematic Algorithms for the Calculation of ATC</u> for Non-PTF Facilities of the Unitil Companies under Schedule 21-FG&E

The following are ATC calculations performed by FG&E for its non-PTF internal interfaces. As consistent with the ISO calculation, the equations for Firm and Non-Firm Available Transfer Capability are:

Firm ATC = (TTC - CBM - TRM - Firm ETC)

Non-firm ATC = (TTC – CBM – TRM – Firm and Non-Firm ETC)

The TRM and CBM for FG&E's non-PTF paths are zero. The purpose of the ETC component of the ATC equation is for the Transmission Provider to define all elements that are reducing the amount of ATC available to the market participant, one such example is point-to-point service commitments. Point-to-point service commitments sharing common transmission paths would be combined through system modeling to calculate the net existing transmission capacity (ETC) impact. This ETC value is then used in the ATC calculation shown above.

The ATC Process Flow Diagram is shown on the next page.

## **ATC Process Flow Diagram for Non-PTF Interfaces**

The process flow diagram illustrates the steps through which ATC is calculated both on an operating and planning horizon.

