Fitchburg Gas and Electric Light Company (FG&E) Transmission Reliability Margin Implementation Document (TRMID)

Records of Revisions

Version	Date	Reason
1.0	April 1, 2011	Original

Introduction

FG&E's Transmission Reliability Margin Implementation Document (õTRMIDö).

Calculation of Transmission Reliability Margin (TRM) on Non-PTF

TRM is the amount of transmission transfer capability set aside to provide reasonable assurance that the interconnected transmission network will be secure. TRM accounts for the inherent uncertainty in system conditions and the need for operating flexibility to ensure reliable system operation as system conditions change. It is used only for external interfaces under the New England market design.

FG&E does not have any external interfaces, and therefore TRM for FG&E & Non-PTF is zero.